



1970-1981 Camaro Chicane Frame Cut-out template

Cut out template from next page. Cut out inner circle to find upper spring cup cut line. Use for both sides by flipping template over. Some further trimming may be required for slight clearancing. We recommend using a cutting torch or plasma cutter to cut the thick metal of the frame. Be sure to use proper safety equipment when cutting and trimming metal.

